




# INSTRUCTIONS / DIRECTIVES / INSTRUCCIONES




**Release corners and remove shield stand**  
Libérez les coins et enlevez le pied du protecteur  
Suelte las esquinas y retire el soporte de la carcasa




**Peel away and remove the outer silicone casing**  
Enlevez la coque externe en silicone  
Extraiga y retire la carcasa exterior de silicona



**Separate the hard plastic case by locating the indicated arrows and unhinging each snap on all four sides of the case**  
Séparez l'étui rigide en plastique en repérant les flèches et détachant les boutons sur les quatre côtés de l'étui  
Separe la carcasa de plástico duro ubicando la zona señalada por las flechas y abriendo los cierres de cada uno de los lados de la carcasa




**Place the device into the bottom half of the hard plastic case**  
Installez l'appareil dans la partie inférieure de l'étui rigide en plastique  
Coloque el dispositivo en la mitad inferior de la carcasa de plástico duro



**Place the lid on top of the device and snap the two halves together, locking the device in place**  
Installez le couvercle sur le haut de l'appareil et attachez les deux moitiés ensemble, ce qui maintient l'appareil en place  
Coloque la tapa encima del dispositivo y encjae las dos mitades, encerrando así el dispositivo.


**DEFENDER SERIES**

[www.otterbox.com/case-instructions](http://www.otterbox.com/case-instructions)



**6**


Wrap the silicone shell around the hard plastic case  
Replacez la coque en silicone sur l'étui rigide en plastique  
Introduzca la carcasa de plástico duro en la funda de silicona



**7**

Pull up on the shield stand hinge to set up the device stand  
Poussez la charnière sur le pied pour l'installer  
Levante la bisagra del soporte de la carcasa para colocar el soporte del dispositivo

## 4 WORKING POSITIONS / 4 POSITIONS DE TRAVAIL / 4 POSICIONES




**A**

Low stand angle – natural typing angle

Position basse – position naturelle d'utilisation du clavier

Poca inclinación del soporte, ángulo natural de escritura




**B**

Low stand angle – portrait orientation

Position basse – orientation portrait

Poca inclinación del soporte, vertical



**C**

**D**

Steep stand angle – portrait orientation

Position debout – orientation portrait

Gran inclinación del soporte, vertical



**C**

Steep stand angle – landscape orientation

Position debout – orientation paysage

Gran inclinación del soporte, horizontal